

The easiest and lightest way to mount them is with Shoego. Add a little drop of Shoego to each end of the stiffener, bring them in the right position and glue them.



if you want't to screw the stiffener,
take a bodyreamer and drill a 3mm hole



M3x6 screw and a M3 nut
(not included)







